




Ordering spares / Ersatzteil - Regelung / Pieces de rechange / Parti di ricambio / Lista de recambios / Onderdelen bestellen (NL/5) / Купи́тели́ запасных частей / Bestilling av reservedeler / Bestilling av reservedeler / Резервные части / Запчасти / Складні запчастини / Pièces de rechange / Beschreibende alfabetslijst / Запчасти / Резервдепозити / Резервни делови / Аксоријелі делів / Teilitavo d'varustad / Reservens delar / Náhradní díly / Náhradní díly / Yedek parça sipariş / Nadomestni deli

XX = AA, AD, ....

- |                 |                  |
|-----------------|------------------|
| 1 - A 861397 NU | 7 - B 964696 NU  |
| 2 - A 961793 NU | 8 - A 962625 NU  |
| 3 - A 861422 NU | 9 - B 961383 XX  |
| 4 - A 861433 XX | 10 - A 861428 NU |
| 5 - B 961707 XX | 11 - A 861434 XX |
| 6 - B 961644 XX |                  |



P 0.3 MPa 3 bar	50°C	15°C	27	33	41	48	50
	65°C	15°C	33	42	53	63	65
	85°C	15°C	41	53	66	83	85





Ideal Standard

**CERAFINE MODEL O**

05.2021 / B565123

B D133 ..



Ideal Standard International NV  
Corporate Village - Gent Building  
Da Vinci 2  
1935 Zaventem  
Belgium

www.idealstandardinternational.com



IS\_CerafineModelO\_B565123\_IGuide\_NN.pdf