



Spare parts	
No.	Description
1	Plastic valve cover 1/4
2	O-Ring
3	Dust cover
4	Plastic valve cover 3/8
5	O-Ring
6	Socket head screw
7	Pump head
8	O-Ring
9	Stop collar
10	Guide vane
11	O-Ring
12	Impeller
13	Mechanical seal
14	Stainless steel seal disk
15	Thrower
16	Holder(PP)
17	handle cover
18	Cross recess pan head tapping screw
19	Plastic handle
20	Bearing
21	Rotor
22	Bearing
23	Stator
24	Pump shell (Aluminium)
25	Corrugated gasket
26	Pump back cover(Aluminium)
27	Hexagonal screw
28	Fan blade
29	Spring check ring
30	Motor housing
31	Screw
32	Sheath
33	Cable impacting
34	Cross recess pan head tapping screw
35	O-ring
36	Side cover(downside)
37	Triangle groove pan head tapping screw
38	Seal ring
39	Waterproof switch
40	Waterproof switch Transparent cover
41	Waterproof switch buckle
42	Capacitor
43	Capacitor buckle
44	Cable