






Spare Parts / Ersatzteile / Pièces de rechange / Pezzi di Ricambio / Piezas de requesto /
 Parte de reposição / Reserveonderdelen / Reservdelar / Reservdeler / Varaosat /
 Vraosat / Varahlutir / Ανταλλακτικά / Yedek Parçalar / Náhradní díly / Náhradné diely /
 Nadomestni deli / Резервни части / Запчасти / Części Zapasowe / Piese de schimb
 / Rendelhető alkatrészek / Зпасні частини / Резервни делови / Резервни делови /
 Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezervju daju

XX = AA, GN, ...

Pos.	Part No.
1	A 861 320 XX
2	B 960 862 XX
4	B 960 650 NU
5	A 861 181 NU
6	A 861 156 NU
7	F 960 985 NU


8	A 960 331 NU
9	A 963 181 NU
10	B 960 486 XX
11	B 960 167 XX
12	A 861 140 NU
13	N 960 006 NU
14	A 961 667 NU

15	A 962 530 NU
16	A 960 242 NU
17	A 962 041 NU
18	A 3306 XG
19	A 861 098 XX



Ideal Standard International NV
 Corporate Village - Gent Building
 Da Vincilaan 2
 1935 Zaventem
 Belgium

www.idealstandardinternational.com



Ideal Standard

Tonic II
 A 6347 ..

0421 / A 868 962
 Made in Germany

