


Ersatzteile - Spare parts - Pièces de rechange - Reserveonderdelen - Parti di ricambio - Reservedele - Reservdelar
 Varaosat - Części zamienne - Náhradní díly - Alkatrészek - Piese de schimb - Запасные части - 备件



| | | | |
|---|---|---|--|
| ① | Kondensator US 75 US 105 US 155 | Capacitor | JP46015 JP46016 JP46017 |
| ② | Schalterschütz | Contacteur | JP46056 |
| ③ | Mikroschalter ES DS | Microswitch | JP46351 JP46352 |
| ④ | Haube ES, DS E, D | Top cover | JP46018 JP46019 |
| ⑤ | Schwimmer | Float | JP46022 |
| ⑥ | Schaltwelle | Switch shaft | JP46020 |
| ⑦ | Schalterpatrone | Switch cartridge | JP46025 |
| ⑧ | Leitung 75 E/ES, 105 E/ES 75 D/DS, 105 D/DS 155 E/ES 155 D/DS with A/NZ plug, E/ES | Cable | JP42777 JP42779 JP46013 JP46014 JP47221 |
| ⑨ | Lagersatz | Bearing set | JP46042 |
| ⑩ | Rotorwelle 75 E 75 D 105 E 105 D 155 E 155 D | Rotor shaft | JP46035 JP46036 JP46037 JP46038 JP46039 JP46040 |
| ⑪ | Stator + Gehäuse 75 E 75 D 105 E 105 D 155 E 155 D | Stator + Housing | JP46027 JP46028 JP46029 JP46030 JP46031 JP46032 |
| ⑫ | Dichtungssatz | Seal set | JP46041 |
| ⑬ | Laufgrad 75 105 155 E 155 D | Impeller | JP46052 JP46053 JP46054 JP46055 |
| ⑭ | Pumpengehäuse | Pump casing | JP46045 |
| ⑮ | Ölschraube | Oil screw | JP46046 |
| ⑯ | Gleitringdichtung | Mechanical seal | JP46043 |
| ⑰ | Schraubensatz | Screw set | JP46263 |
| ⑱ | FüBe | Feet | JP46047 |
| ⑲ | Deckel | Cover | JP46051 |
| ⑳ | Motorschutz 155 ES 155 DS | Motor protection Schuko-plug CEE-plug | JP40264 JP44750 |
| ㉑ | 1l Öl | 1l Oil | JP48236 |